




Cleaning Solutions and Rowmark Products

Rowmark Product	Furniture Polish (Pledge®)	Isopropyl Alcohol	All Purpose Cleaner (Formula 409®)	Dish Soap (non citrus)	Window Cleaner	Bleach Cleaner (Clorox®)	Citrus Cleaner (Goo Gone®)	Novus Plastic Polish (Level 1)	PineSol® Cleaner	Lysol® Spray	Dow® Bathroom & Tile Cleaner	Lysol® Basin, Tub & Tile	Lacquer Thinner	Lighter Fluid
ADA Alternative®	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
ColorCast Acrylics	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Earthtones	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
FlexiBrass® & FlexiColor®*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Granites Deluxe™	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Heavy Weights	😊	😊	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Lacquers	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
LaserLIGHTS	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
LASERmag	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
LaserMark®*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
LaserMax®*	😊	😊	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Mattes	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Multigraph	😊	😞	😞	😊	😞	😞	😊	😊	😊	😞	😞	😞	😊	😊
Metalgraph Plus	😊	😊	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
NoMark® Plus*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Outdoor Weatherable Metals	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Reverse LaserMark®*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Satins	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Silks	😊	😊	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Slickers	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Standard Metals*	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Textures	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Ultra-Mattes Front Engravable	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊
Ultra-Mattes Reverse Engravable	😊	😞	😊	😊	😊	😊	😊	😊	😊	😞	😞	😞	😊	😊

-  safe to use
-  use sparingly
-  not recommended

* Metallic foils are metal based and are prone to oxidation in high humidity environments.

When lasering Rowmark materials, it is helpful to first vector cut the file with the masking on, and then remove the masking to raster engrave. Doing this keeps the masking on the unused material for later use and can reduce cleaning time for the current project.

Tips for cleaning Rowmark sheet products:

1. As a general rule, *Rowmark recommends using mild soap and water whenever possible.*
2. Test a piece of scrap or small area of the material before cleaning entire piece.
3. Use only soft cloths or sponges for cleaning. Do not use Brillo®/S.O.S.® pads or steel wool.
4. Use a Q-Tip® to clean small areas.
5. Rinse with warm water.
6. Ultrasonic cleaning is NOT RECOMMENDED for *any* Rowmark product.
7. To remove dust from engraved areas, try compressed air before any solvent cleaner.
8. Cleaners with abrasives, such as Comet® brand cleaner, are not recommended.